


3

Installation using the instruction manual



MODEL : RV-8035

A		X2	H		X2
B		X2	I		X2
C		X2	J		X4
D		X2	K		X4
E		X4	L		X8
F		X2	M		X12
G		X2	N		X4

ST4X30
ST4X16
ST4X10
φ3.0

A		H	
B		L	
C		N	
E			

ST4X30
ST4X10

200cm
30cm
60cm
90X90

1

D	
I	
J	
K	

2